

**PLAN VIEW**


**NOTES**

1. Contact Underground Service Alert (USA) @ (800) 642-2444 at least 5 days prior to beginning excavation work to locate existing utilities.
2. Build soil berm min. 4" high and 2' from tree trunk in planter strip. Provide loam topsoil needed to form berm and fill holes.
3. Soil, concrete and other materials spilled on street, sidewalk, and planting area shall be cleaned up immediately by Contractor.
4. PVC root barrier may be required on a site specific basis.

Rev	By	Date
0		12/14/92
1	Ron L	04/15/03
2	JT	08/14/06
3	HQN	03/19/07

**Tree Detail  
Planter Strip**

**City of Palo Alto Standard**

Approved by:  
  
 PE No. **35411**  
 Date **5/14/07**

Dwg No. **604**

Scale: NTS